



## Hot/Cold Oven Operation Instructions

8/25/2020

The holding oven in the Hot/Cold Transit Connect is heated by engine cooling system and is controlled by fans that recirculate air inside holding through heating cores, similar to heater core in cab of van. The fans are controlled by a temperature controller mounted to control panel on bulkhead in cab. The temperature can be set between 140 and 200 degrees and is factory set at 180 degrees. Please note that in colder weather the unit will take longer to heat up at idle, driving the vehicle will heat oven faster as engine is producing more heat.

To change the temperature:

- First turn on controller with switch to left of controller, LED display will flash and then will read current oven temperature.
- Push SET button and release, display will read SP1
- Push SET button and release, display will read set temperature, 180 degrees factory setting.
- Push UP or Down Arrows to set at desired temperature and push SET button, in 15-20 seconds display will switch back to current oven temperature reading.
- Oven will now heat to desired temperature.



31 Industrial Park  
Road  
Wapato, WA  
98951  
USA

PHONE (509) 949 4747  
FAX (509) 722 9004  
EMAIL [admin@patriotcompanies.us](mailto:admin@patriotcompanies.us)  
WEBSITE <http://patriotcompanies.us>