



Second/Additional Compartment Controller Operations

8/24/20

- To Turn Controller On Select “Red” rocker switch to right of LED panel
- Rocker switch light will come on and turn “Red”
- The light will blink for a few seconds and the current set temperature will display

- To Select Temperature Press and quickly release “set” button
- “Set” on “Pb1” will display
- Press “up” or “down” arrows until “Set” appears
- Press “Set” button and release
- Set point temperature will display
- Press “up” or “down” arrows to change set point
- Wait 15 seconds or press “FNC” and unit will return to temperature



31 Industrial Park
Road
Wapato, WA
98951
USA

PHONE (509) 949 4747
FAX (509) 722 9004
EMAIL admin@patriotcompanies.us
WEBSITE <http://patriotcompanies.us>